



Pre-install Instructions

1. Prior to painting your part, please test the fit of this part on your truck to ensure this is the correct one.
2. Wash the hood with a mixture of mild soap or dishwashing liquid and water using a soft sponge. Rinse with clear water. Use mineral spirits to remove surface stains.
3. Clean the surface using any solvent to remove mold release agents, wax, dirt, and other greasy agents.
4. Sand the hood surface lightly using 400-600 grit wet sand paper. This step will help guarantee a good adherence of the primer and top coat.
5. Clean the hood with clear water, and then apply paint thinner to remove all dirt and grease from the surface.
6. Apply the fiberglass primer of your preference to the surface and cover the entire area. Make sure the primer is suggested for use with the top coat paint you plan to use.
7. If necessary, sand and clean again before painting.